

FUSEFINDER2

PRODUCT DATA SHEET

FUSEFINDER2

- Transmitter to inject a high frequency signal on the circuit under test
- Receiver to detect circuit with signal at the distribution board
- Clear LED indication of signal strength
- Receiver auto-tunes sensitivity
- Scanning sensitivity reset button
- Ferrite transducer scanning head
- Receiver - auto power off



ACCESSORIES

- Mains Lead Cable for transmitter
- Instruction Manual
- Batteries 2 xAA (not included)

OPTIONAL

ACC016E: three wire distribution board leads for connection to lighting circuits

SPECIFICATIONS

Standard Standard	IEC 61010 250V CAT III, <input type="checkbox"/> Double insulated
Transmitter supply	110V / 230V 50-60Hz
Transmitter current	<20mA
Receiver Batteries	2 x AA Alkaline